







Operating instruction - pal 101





Door opening





Call waiting



To initiate call to the door or gates panel



All the Phones will ring again for somebody else to pick up



Intercom on the same line